

TECHNICAL SPECIFICATION

RESPIRATORY PROTECTION



MARTCARE®

Moulded Disposable Mask - M21 - FFP2

Box of 20 / Code: BEG120-002-B00



Description

Moulded disposable respirator with foam padded nose bridge

Options

Box of 20 (BEG120-002-B00)



JSP Limited, Worsham Mill, Minster Lovell, Oxford OX29 0TA, England.
Tel: +44 (0)1993 826050 / Fax: +44 (0)1993 824411 / Email: sales@jsp-safety.com / Web: www.jsp-safety.com
Do Not Publish without written permission from JSP Limited. Contact copyright@jsp-safety.com.
Information correct in the United Kingdom at date of issue and may be subject to change. Any third-party machine and automated translations processed by users may have inaccuracies and should not be relied upon.
Page 1 of 3 / Issued 16 Nov 2020 / Copyright 2018 - 2020. JSP Limited. All Rights Reserved.




www.jsp-safety.com

sales@jsp-safety.com

UK tel: +44 (0)1993 826050

FEATURES



FOAM PADDED NOSE BRIDGE, A mouldable nose bridge with foam area around the inside provide comfort and a firmer fit

SAFETY STANDARDS

EN 149:2001 + A1:2009
CE 735666 issued by BSI

SPECIFICATIONS

Classification

FFP2 (Filtering Facepiece Particulate)

Filter Type

P (Protects Against Solid and Liquid Aerosols)

Usage

NR (Non-Reusable)



(D) Resistance to dust clogging

Yes - D marking = passes optional clogging test



Activated Carbon Layer

No



Minimum Filtration Efficiency

94% For FFP2 Rated

Maximum Total Inward Leakage (TIL)

8%

Nominal Protection Factor (NPF)

12

UK Assigned Protection Factor (APF)

10

Mask Design

Moulded



Exhalation Valve

No



Nose Bridge

Moulded in mask

Mask Material

Polypropylene

Filter Shelf Life

5 Years



Product Weight

16g (Approx)

COMPATIBLE PRODUCTS

EVO® Gas Goggle
EVO® Goggle Double Lens
EVO® Goggle Single Lens
Sonis® Compact Ear Defenders
Sonis®1 Ear Defenders
Sonis®2 Ear Defenders
Sonis®3 Ear Defenders
Stealth™ 16G
Stealth™ 7000
Stealth™ 8000
Stealth™ 9000
Stealth™ Coverlite™ Overspec
Thermex™ Double Lens Goggle

ACCESSORIES

Portacount/AccuFIT Quantitative/Qualitative Face Fit Testing Kit & Spares

APPLICATIONS

- Mining, Aggregates and Quarrying
- Agriculture
- Forestry & Landscaping
- Manufacturing
- Constuction & Infrastructure
- Scaffolding & Roofing
- Welding (mild)



JSP Limited, Worsham Mill, Minster Lovell, Oxford OX29 0TA, England.

Tel: +44 (0)1993 826050 / Fax: +44 (0)1993 824411 / Email: sales@jsp-safety.com / Web: www.jsp-safety.com

Do Not Publish without written permission from JSP Limited. Contact copyright@jsp-safety.com.

Information correct in the United Kingdom at date of issue and may be subject to change. Any third-party machine and automated translations processed by users may have inaccuracies and should not be relied upon.

Page 2 of 3 / Issued 16 Nov 2020 / Copyright 2018 - 2020. JSP Limited. All Rights Reserved.



INSTRUCTIONS FOR USE

- Mask must be fitted in accordance with the instructions supplied
- Care must be taken to ensure that the correct mask type is selected for the work to be carried out
- If in doubt as to the type of mask required, seek professional guidance

CLEANING & MAINTENANCE

- Not Applicable - Disposable Product
- Store the masks out of sunlight away from chemicals in a dry atmosphere

DIMENSIONS OF MASK

- Depth: 6.5cm / Width: 15cm / Height: 13.5cm

DIMENSIONS OF BOX

- Depth: 135mm / Width: 135mm / Height: 180mm

DIMENSIONS OF OUTER PACKAGING

- Quantity: 200 (10 inner packs of 20 masks)
- Depth: 690mm / Width: 285mm / Height: 195mm

LIMITATIONS OF USE

- Protection will only be offered if the mask is fitted correctly
- The mask, when in contact with the skin may cause allergic
- Do not use where exposure to chemical gases may be experienced
- Use in well ventilated areas only, which are not deficient in oxygen and do not contain explosive atmospheres
- Ensure good seal around the face is created before entering the hazard area
- The working life of the mask is nominally one day (this is based on a working day shift of 8 hours), however it may be affected by many factors, including work rate, airflow and concentration of any contaminant in the atmosphere. The mask should be changed immediately if,
 - a.) Breathing difficulties due to clogging are experienced,
 - b.) Breakthrough of a contaminant is detected by smell, taste or any other means, or
 - c.) The mask becomes damaged

